
# **Treatment of Mixed Waste Coolant**

Scott Kidd John S. Bowers

This paper was prepared for submittal to HAZMACON 1995 San Josde, CA April 4-6, 1995

February 1995

This is a preprint of a paper intended for publication in a journal or proceedings. Since changes may be made before publication, this preprint is made available with the understanding that it will not be cited or reproduced without the permission of the author.



## DISCLAIMER

This document was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor the University of California nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or the University of California. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or the University of California, and shall not be used for advertising or product endorsement purposes.

#### TREATMENT OF MIXED WASTE COOLANT

Scott Kidd John S. Bowers Lawrence Livermore National Laboratory Hazardous Waste Management Division Livermore, CA 94550

#### **ABSTRACT**

The primary processes used at Lawrence Livermore National Laboratory (LLNL) for treatment of radioactively contaminated machine coolants are industrial waste treatment and *in situ* carbon adsorption. These two processes simplify approaches to meeting the sanitary sewer discharge limits and subsequent Land Disposal Restriction criteria for hazardous and mixed wastes (40 CFR 268). Several relatively simple technologies are used in industrial water treatment. These technologies are considered "Best Demonstrated Available Technologies," or BDAT, by the Environmental Protection Agency.

The machine coolants are primarily aqueous and contain water soluble oil consisting of ethanol amine emulsifiers derived from fatty acids, both synthetic and natural. This emulsion carries away metal turnings from a part being machined on a lathe or other machining tool. When the coolant becomes spent, it contains chlorosolvents carried over from other cutting operations as well as a fair amount of tramp oil from machine bearings. This results in a mutiphasic aqueous waste that requires treatment of metal and organic contaminants.

During treatment, any dissolved metals are oxidized with hydrogen peroxide. Once oxidized, these metals are flocculated with ferric sulfate and precipitated with sodium hydroxide, and then the precipitate is filtered through diatomaceous earth. The emulsion is broken up by acidifying the coolant. Solvents and oils are adsorbed using powdered carbon. This carbon is easily separated from the remaining coolant by vacuum filtration.

#### INTRODUCTION

Coolants are a complex form of multilayered heterogeneous waste. At LLNL, the term "coolant" describes waste that is generated in metal cutting. This waste has been considered difficult to treat to meet either land disposal restrictions, National Pollution Discharge Elimination System (NPDES) discharge limits, or both. Because most of the matrix is water, the logical approach is to treat the entire waste stream in an industrial aqueous waste treatment setting using a variety of industrial treatment techniques.

Although there is some diversity in the constituents, the range of contamination, and the original product makeup among coolants, the treatment techniques used are the same.

#### WASTE STREAM GENERATION AND MAKEUP

Coolant, as product, is primarily made up of a proprietary emulsion concentrate and water (90% water by volume). The concentrate includes triethanolamine, polyoxyethylene nonionic surface agent, pine oil, dimethyl silicone polymer (antifoam), alkali borate (rust inhibitor), and fungicide and bactericide (phenol derivative). This material is mixed with water to form a 10% solution by volume.

An emission spectroscopy performed on the solution yielded the following results:

Table 1. Emission Spectroscopy Results for Raw Coolant Solution.

Constituent	Concentration
Boron	1%
Sodium	0.2%
Potassium	0.1%
Silicon	500 mg/L
Calcium	300 mg/L
Iron	100 mg/L
Magnesium	25 mg/L
Aluminum	10 mg/L
Copper	40 mg/L

The coolant is pumped from a reservoir to the metal part that is being machined using a mill or a lathe. The stream of coolant is directed onto the metal part at the tool interface. The coolant's purpose is to sweep away metal turnings as the tool cuts into the part. The coolant also keeps the tool-part interface cool and lubricated. The coolant is recirculated by continually directing the flow of the coolant to the tool interface and allowing the coolant to fall back into the reservoir.

Occasionally, parts are cut using tetrachloroethylene as a coolant such as when parts are made from titanium. Other coolants are used for cutting magnesium, lead, and other metals, because triethanolamine is quite corrosive to these metals.

Other contaminants (methyl chloroform and oil) are found in the coolant. These contaminants are from residues on the metal part or from basic operation and maintenance of the machining equipment. The parts are occasionally degreased with methyl chloroform. The methyl chloroform can carry over into the coolant when the part is placed back on the lathe or mill. Operation and maintenance of the mills and lathes allows for oil (tramp oil) to be deposited into the coolant reservoir.

The coolant is no longer used when it contains too much metal, oil, and or chlorosolvent. After a while, the coolant may also get rancid due to bacterial decay. When the coolant is spent, it is vacuumed up with a wet/dry vacuum or sump sucker and transferred from the reservoir(s) into drums. It is then shipped to the aqueous waste treatment facility for treatment and subsequent disposal.

LLNL composited and sampled approximately 260 drums of spent coolant. The sampling method consisted of using a drum stirrer and mixing the solution for 1 minute to ensure that particulate metals and heavy solvents were representatively mixed into the fluid, then using a long glass tube or a Composite Liquid Waste Sampler (COLIWASA) to collect the material. The samples were analyzed for:

- pH using a pH electrode
- Percent oil by volume using a graduated cylinder and measuring the phases after settling

- Organics using EPA SW-846 Methods: 8010, Halogenated Volatile Organics, and 8020, Aromatic Volatile Organics
- Metals using EPA SW-846 Methods: 6010, Inductively Coupled Plasma Atomic Emission Spectroscopy; 7470, Mercury in Liquid Waste/Manual Cold-Vapor Technique; 7061, Arsenic/Atomic Absorption, Gaseous Hydride; and 7741, Selenium/Atomic Absorption, Gaseous Hydride
- Gross alpha and gross beta using approved preparation and counting methods
- Tritium using distillation and scintillation counting.

The results of these test are given below in Table 2.

**Table 2. Analytical Results for Spent Coolant.** 

Constituent	Concentration	<b>Detection limit</b>
pH*	9.67	N/A
Percent unemulsified oil	1%	N/A
Antimony	<9 mg/L	9 mg/L
Arsenic	0.26 mg/L	0.02 mg/L
Barium	1.4 mg/L	0.02 mg/L
Beryllium	10 mg/L	0.02 mg/L
Cadmium	0.3 mg/L	0.1 mg/L
Chromium	0.51 mg/L	0.04 mg/L
Cobalt	0.2 mg/L	0.2 mg/L
Copper	11 mg/L	<0.03 mg/L
Lead	9.3 mg/L	0.6 mg/L
Manganese	2.1 mg/L	0.04 mg/L
Mercury	<0.06 mg/L	0.06 mg/L
Molybdenum	2.9 mg/L	0.03 mg/L
Nickel	2.1 mg/L	<0.05 mg/L
Selenium	<0.02 mg/L	0.02 mg/L
Silver	0.04 mg/L	0.03 mg/L
Thallium	<0.1 mg/L	0.1 mg/L
Vanadium	0.4 mg/L	0.06 mg/L
Zinc	63 mg/L	0.6 mg/L
Tetrachloroethylene	540 mg/L	10 mg/L
Methyl chloroform	680 mg/L	10 mg/L
Gross alpha	0.107 Bq/L	0.003 Bq/L
Gross beta	0.145 Bq/L	0.005 Bq/L
Tritium	0.052 Bq/L	0.018 Bq/L

<sup>\*</sup> pH by hydronium mass balance

Mixing is needed to obtain a representative sample of the waste and to reach material that may have settled to the bottom of the tank. Although it may cause some release of volatile constituents (e.g., tetrachloroethylene and methyl chloroform), mixing prevents the problem of not being able to collect sediment at the bottom of the tank, which is a major source of the contamination. The escape of volatiles is minimized by the short mixing duration and by the limited space (two small bung holes in the drum) for molecular diffusion and subsequent release into the atmosphere.

#### PRINCIPLES USED IN TREATING COOLANTS

The methods used for removing radionuclides and metals from industrial waste water treatment are usually described as precipitation, flocculation, and filtration. Table 2 shows that antimony, mercury, selenium, and thallium were not found above detection limits, and arsenic was not significantly high. The gross alpha and beta concentration is most likely from natural and depleted uranium. Although some thorium gets machined, compared to uranium, very little of this material is generated. The tritium is not a concern here because it is below what the discharge criteria is for disposal with the Publicly Owned Treatment Waterworks (POTW) NPDES permit.

Organics are usually treated with carbon canisters in the water phase, but this method does not work well for mixed waste. Carbon canisters are not used for the following reasons:

- 1. A substantial amount of oil in the waste causes frequent saturation of carbon, resulting in added costs for using more canisters.
- 2. The carbon canister becomes slightly contaminated with radioactivity and prevents cost-effective measures for commercially recycling the carbon canisters.

Several principles are used to precipitate industrial waste. The most important are based on:

- Optimizing pH on metals that are amphoteric in nature
- Increasing solubility by calculating the ionic strengths and reducing the activity coefficient of the solute
- Calculating the oxidation-reduction potential or net potential difference as a function of pH as in an pE-pH (Pourbiax-diagrams) chart and then adjusting the pH for desired solubility.

Many metals are amphoteric. These metals are weak acids; at low-to-moderate pH, they precipitate out at an optimum pH, and then they become weak bases or form complex hydroxides at an elevated pH. Formation constants and hydroxide solubility product for most common metal hydroxide complexes and precipitates are given in Lange's *Handbook of Chemistry*. Calculations can be performed using these values to determine the optimum pH (i.e., the pH at which the metal is least soluble). These optimum pH values are given in Table 3 for a few metals.

Table 3. pH of Lowest Solubility.

Constituent	рН	Concentration in (mg/L) at Given pH Wh the Activity Coefficients Are Unity	
Beryllium (+2)	9.2	0.0009	
Cadmium (+2)	11.6	0.005	
Chromium (+3)	8.0	0.004	
Copper (+2)	9.0	0.02	
Lead (+2)	10.6	16.4	
Nickel (+2)	10.8	0.03	
Zinc (+2)	9.4	0.005	
UO <sub>2</sub> (+2)	6.2	7.1 (88 Bq/L)	
PuO <sub>2</sub> (+2)	7.8	0.00004 (91 Bq/L)	

Other precipitation techniques are available, but most deal with agents that are more toxic and less environmentally sound than hydroxide. Sulfide salt is a great precipitating agent that is very pH insensitive and has extremely low solubility products. The difficulty with using sulfide is that it has a low odor threshold, it creates a toxic gas in acidic conditions, and is difficult to disperse in liquid. Nevertheless, it is used as a polishing treatment. As one can see, lead concentrations are high when standard hydroxide precipitation is used.

Ionic strengths of coolant are often high because of the high concentrations of dissolved salts and the type of chemical that is added to the coolant when precipitating metals. Usually activity coefficients cannot be estimated accurately due to high ionic strengths. The Debye-Hückel expression cannot be used when the ionic strengths exceed about 0.01 mol/L. For solutions with moderate ionic strengths, a modification to the Debye-Hückel expression given by Robinson, Guggenheim and Bates can be used. The modified expression can be found in Lange's *Handbook of Chemistry* and is given below:

$$Log f = bI - \frac{Az^2 \sqrt{I}}{1 + B\mathring{a}\sqrt{I}}$$

f = Activity coefficient

b = Constant (0.2 for water solvent)

I = Ionic strength

A = Constant (0.5115 for water, 25°C)

Z = Valence of the solute

B = Constant (0.3291 for water, 25°C) å = Ionic radii of the aqueous solute

The activity coefficient calculated for the waste is approximated using sodium sulfate as the primary solute with an ionic strength of 0.081 mol/L. Using the modified expression, the activity coefficient for the waste is approximately 0.4. The use of sodium sulfate increases the solubility of the solution by 2.5 because actual solubility is estimated by dividing the ideal solubility by the activity coefficient.

The behavior of precipitation is influenced by potential differences residing in the waste water in the form of a pE-pH diagram. This is usually measured in industrial waste water by oxidation-reduction potential. This measurement determines if the environment is an oxidizing environment or a reducing environment, which is important because metals have the lowest solubility at the highest oxidation state. The range of potential in water as a function of pH is valuable to know because it provides an understanding of the environment affected by coolants. Figure 1 shows the stability region for water by plotting electron concentration as a function of pH. The higher the electron concentration, the higher the reduction potential. The lower the electron concentration, the higher the oxidation potential. So, with low electron concentrations, the results yield higher metal oxidation states and lower solubilities.




Figure 1. Water Stability Electron Concentration as a Function of pH.

Organics can be treated in the same setting as industrial waste water. Figure 1 also sheds light on ways to deal with organics. If the oxidation potential is high, organics can be broken up into smaller molecules by oxidation. This is practiced by adding oxygen to the coolant in the form of hydrogen peroxide and iron salt (Fenton's Reagent). Organics, even halogenated organics, can be broken up into carbon dioxide and halidic acids by the use of this material. Saturated bonds like those in many oil constituents are also destroyed.

Low-grade activated carbon is used and added to coolant to remove the remaining organics. This is simpler in principle than using columns or adding granular activated carbon because the Freundlich Isotherms for this material apply directly. The low-grade activated carbon is also readily available through carbon manufacturers. For each carbon type, there are two parameters given for each adsorbing species.

These parameters are used in an isotherm equation, presented below:

$$Q = KCn$$

Q = Concentration of contaminant on carbon (usually mg/g)

 $\vec{K}$  = Freundlich isotherm parameter

C = Concentration of contaminant in coolant (usually mg/L)

n = Freundlich isotherm parameter

An estimate the amount of carbon to add is based on the original constituent concentration and this equation.

## SEQUENCE OF TREATMENT

Once a methodology has been developed based on the principles discussed above, treatment of the coolant waste can begin. In the overall treatment sequence, waste coolant is put into the waste water treatment plant. The waste water treatment plant consists of a rotary-drum vacuum-filter (RDVF) unit and several 7000-L (1,850-gal) capacity tanks that are equipped with stirrers.

The coolant is placed into a tank and mixed. The coolant pH is dropped to about 3.0 by adding sulfuric acid. This breaks up coolant emulsion and facilitates the oxidation reaction to follow. Hydrogen peroxide is added to the coolant, which raises the oxidation states of all the metals and breaks up the oil and organic film.

At this point, you can detect oxygen and carbon dioxide gases being emitted from the solution. Foaming occurs at this stage, but it is not substantial and often subsides during filtration. Ferric sulfate is added after hydrogen peroxide. The ferric sulfate serves as a flocculant and destabilizes the charge around the precipitate that will be formed later.

The coolant now has very little oil on its surface. Precipitates form as the orange color caused by the ferric sulfate swirls around the tank. These precipitates are saturated sulfate salts. In many cases, sulfates have low solubility but low not enough to preclude hydroxide precipitation. After mixing the tank for several minutes, sodium hydroxide is added to precipitate the metals. Usually the precipitation will be carried out at a pH of 9.0, but high radioactivity concentrations are reduced more efficiently at higher a pH (usually around 12).

Once the sodium hydroxide has been added to the coolant, the solution is allowed to mix for at least 20 minutes. During this time, valves are lined up to route the tank contents to the RDVF. After performing the valve line up, carbon is added to the coolant solution. The carbon adsorbs the remaining organic constituents and is filtered out along with the precipitates. The filter used in the RDVF system to trap the spent carbon and precipitates is a diatomaceous earth media. The filter cake residue (i.e., diatomaceous earth, spent carbon, and precipitates) is cut off the rotary filtration drum and stored for further stabilization.

The effluent leaves the filter clear and relatively colorless. If metals such as lead, radionuclides, or other contaminants are still present at unacceptable levels, the waste is treated again. If the constituents are low enough in concentration, sulfide will be used as a polishing treatment.


#### **RESULTS**

Table 4 shows typical before and after treatment analysis. The analyses were performed using the Environmental Protection Agency's *Test Methods for Evaluating Solid Waste*, *Physical/Chemical Methods* (EPA publication SW-846). For these particular samples, organic concentrations were lower than the composite given in Table 2. Organic concentrations before treatment and after one or more treatments are given in Figure 2. Data reported in Figure 2 are for organics that can be extracted by Freon 113.

Table 4. pH of Lowest Solubility.

Туре	Before Treat	After Treat	Before Treat	After Treat	Before Treat	After Treat	Before Treat	After Treat
Batch Number	92-06	92-06	92-07	92-07	92-13	92-13	92-16	92-16
Sample No.	9103001	9200025	9200169	9200165	9200563	9200626	9200662	9200738
Liters	4901	5046	5046	5046	4685	5118	4974	5046
CAM-WET Meta	als in mg/	L (ppm)						
Antimony	< 0.6	< 0.6	< 0.6	< 0.6	0.800	< 0.9	< 0.9	<0.8
Arsenic	0.020	0.050	ND	0.007	0.006	< 0.001	0.010	0.005
Barium	4.500	0.520	10.000	0.052	0.120	0.010	0.120	0.006
Beryllium	1.800	0.089	0.190	< 0.003	0.066	< 0.004	0.020	< 0.004
Cadmium	0.100	< 0.02	0.040	< 0.02	0.760	< 0.02	0.360	< 0.03
Chromium	17.000	4.200	0.770	0.230	16.000	0.730	5.400	1.000
Cobalt	0.090	0.100	0.070	0.050	0.500	0.040	0.440	< 0.03
Copper	36.000	16.000	4.200	0.670	34.000	0.057	24.000	0.096
Lead	9.700	0.500	0.880	< 0.04	2.300	< 0.05	1.700	0.060
Manganese	6.100	0.490	0.890	< 0.006	7.700	< 0.006	1.300	0.007
Mercury	2.200	0.410	0.160	< 0.005	0.049	< 0.003	0.006	< 0.003
Molybdenum	0.440	0.630	0.290	0.350	1.900	1.000	3.200	2.000
Nickel	9.600	4.600	1.100	0.500	340.000	0.420	63.000	0.120
Selenium	< 0.001	0.006	ND	< 0.002	< 0.001	0.033	0.003	0.100
Silver	2.500	0.350	0.110	< 0.005	2.800	0.010	0.079	< 0.006
Thallium	0.030	< 0.01	< 0.01	< 0.02	0.720	< 0.01	< 0.01	< 0.02
Vanadium	0.490	0.440	0.110	0.088	0.910	0.250	0.640	0.040
Zinc	8.200	0.900	20.000	0.300	9.600	< 0.07	4.600	0.100
RAD ANALYSIS								
alpha (μCi/ml)	3.70E-04	5.40E-05	1.30E-05	ND	2.10E-06	ND	1.20E-07	ND
beta (μCi/ml)	3.00E-05	2.00E-05	6.80E-06	3.10E-07	2.10E-06	ND	ND	ND
tritium (µCi/ml)	2.00E-04	1.80E-04	2.10E-05	2.70E-05	2.80E-05	2.10E-05	6.30E-06	5.10E-06

Figure 2. Organic Concentrations Before and After Treatment(s)



### **CLOSING STATEMENT**

Radioactive waste coolants can be treated successfully with industrial waste water methods by applying the principles of pH optimization, ionic strength, oxidation-reduction potential, and carbon adsorption principles.

## **ACKNOWLEDGEMENT**

Work performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under Contract W-7405-ENG-48.

Technical Information Department • Lawrence Livermore National Laboratory University of California • Livermore, California 94551